



Step 1:
Click **Fixed**.



Step 2:
Click **+** to begin a new program.




Step 3
Change λ_1 to **504**.




Step 4

Fill the cuvette to three-fourths height with blank sample (water). Then put the blank sample into the sample pool, then click **Blank**.



Step 5

Fill the cuvette to three-fourths height with the most dilute standard. Put the cuvette to be tested into the sample pool, then click **Measure**, record the absorbance at 504 nm.



Step 6:

Then, use the next most concentrated standard to condition the cuvette. Fill it to three fourths height, click **Measure** and record the absorbance.

Step 7:

Repeat step 6 with all tested samples and record the absorbance.